

# BUNN®

SINCE 1907 THE ORIGINAL  
PACKAGE TYING MACHINE

## TYING MACHINES

### Operator's Manual



#### B. H. BUNN COMPANY

12550 South Lombard Lane, Alsip, Illinois 60658  
Telephone: 312/388-7600


#### B. H. BUNN INTERNATIONAL LTD.

12550 South Lombard Lane, Alsip, Illinois 60658

CABLE: "BUNNITYCO"

## S-10-E

- Quickly ties packages.
- Automatically adjusts to size.
- Any shape—any size.
- Ties small parts, irregular shapes, soft packages, cartons and publications.



Printed in U.S.A.

# Operator's Manual

## CONTENTS

I /	INTRODUCTION	1	VI /	PARTS LIST	14
	PURPOSE OF TYING MACHINE	1		MAIN TABLE ASSEMBLY	15
	GENERAL DESCRIPTION	1		KNOTTER HEAD ASSEMBLY	16
	PRINCIPLES OF OPERATION	1		STRINGHOLDER AND KNIFE TRAP ASSEMBLY (Dual Tension)	17
	Single Wrap One-Way	1		MAIN CAM ASSEMBLY	18
				MAIN TABLE SUPPORT AND KICKOUT ASSEMBLY	19
				TWINE ARM & DRAWBACK	
II /	PREPARATION FOR USE	3		LEVER ASSEMBLY	19
	UNCRATING INSTRUCTIONS	3		CLUTCH ASSEMBLY	20
	POWER REQUIREMENTS	3		MAINSHAFT, MAIN GEAR & CHAIN GEAR ASSEMBLY	21
	TYING MATERIALS	3		MISCELLANEOUS	23
	ILLUSTRATED THREADING PROCEDURES	4			
III/	OPERATION	6			
	BEFORE OPERATION CHECKS	6			
	ONE-WAY WRAP OPERATION	6			
	AFTER OPERATION PROCEDURES	7			
IV/	MAINTENANCE	7			
	INTRODUCTION	7			
	TABLE OF PREVENTIVE MEAINTEENANCE CHECKS AND SERVICES	8			
	TABLE OF LUBRICATION REQUIREMENTS	9			
V /	TROUBLESHOOTING	12			
	TABLE OF TROUBLESHOOTING INFORMATION	12			

## LIST OF ILLUSTRATIONS

1. Positioning Package for Tying	6
2. Knotter Head Assembly Lubrication Diagram	9
3. Stringholder Assembly Lubrication Diagram	9
4. Main Table Lubrication Diagram	10
5. Transfer Gear Lubrication Diagram	10
6. Drive Assembly Lubrication Diagram	11

1947

1948

1949

1950

1951

1952

1953

1954

1955

1956

1957

1958

1959

1960

1961

1962

1963

1964

1965

1966

1967

1968

1969

1970

1971

1972

1973

1974

1975

1976

1977

1978

1979

1980

1981

1982

1983

1984

1985

1986

1987

tie mail, packages, cartons, pieceparts, printed matter, newspapers, laundry, produce, meat, corrugated cardboard, and miscellaneous materials and products requiring a secure wrap. The tying machine ties almost everything that was previously wired, banded, taped, strapped or previously tied by hand in offices, factories, and commercial establishments. The tying machine reduces tying time, employee effort and fatigue, reduces twine lint and twine waste, enables trained operators to make secure ties quickly, ties larger bundles with greater ease and efficiency, and discourages tampering because the knot cannot be duplicated by hand tying.

## GENERAL DESCRIPTION


The tying machine is of steel, cast iron, and high impact plastic construction. Heavy duty panels and guards completely enclose the moving parts of the tying machine to prevent accidental operator contact. However the unique design of the tying machine still provides the operator with easy accessibility to maintenance points without the use of tools. For ease of mobility caster wheels are used. A break feature on each caster resists movement of the tying machine when assigned a permanent position. The "on-off" switch (used to supply electrical power) and a foot pedal (used to initiate the tying cycle) are within easy and comfortable reach of the operator. The material tying area consists of a front table, back table and standard. The standard is used as a positioning guide for the material to be tied when placed on the front and back tables. A knotter head assembly, stringholder assembly, twine arm, and drive assemblies comprise the tying cycle components.

## PRINCIPLES OF OPERATION

### *SINGLE WRAP ONE WAY*

With the tying machine power cord connected to an appropriate power source and the material to be tied properly positioned on the front table and back table, the operator then places the "on-off" switch in the "on" position. Electrical ac power is then transferred by the switch to start the motor. The motor rotating at approximately 1725 RPM drives the pulley assembly on the clutch shaft via the V belt mechanically coupling the pulley assembly to the motor. At this time, the tying machine is considered to be in a locked condition until the operator applies toe pressure to the foot

Repositioning the kickout wedge permits the lever clutch of the kickout mechanism to first pull away from the clutch kickout block on the main cam assembly and then is engaged by the fork clutch. As soon as this occurs, the clutch shaft becomes unlocked and starts to rotate which in turn drives a series of gears; main shaft main gear and chain gear. As a result, the twine arm begins to swing around the package being tied pulling the twine from the cone pilot assembly, through the properly adjusted tension device and each threading guide. After the swing of the twine arm, the drawslide is positioned to allow the twine to fall directly behind the stringholder button. The drawslide then pushes the



tinuing its arc and the stripper is holding the twine in position until the knotter body turns counter-clockwise opening its jaws for the two strands of twine which are wrapped around the knotter body assembly. The strands of twine are brought through the jaws and the jaws firmly lock. The knotter body assembly then moves toward its finished position and the stripper forces the twine strands off the knotter body as-

and pulls the previously cut end of the twine from behind the stringholder button. The knotter body assembly completes its movement to the finished position and the knotter body assembly jaws open to release the loops, completing the tying process.

The tied bundle is then removed from the tying machine.

To perform the uncrating instructions, a pry-bar or hammer will be required.

1. Using a pry-bar or hammer, carefully remove the top wood slats and then the side wood slats secured to the bottom skid.

2. Open the top of the protective plastic bag enclosing the tying machine.

3. Raise the plastic bag free from the tying machine.

#### NOTE

The plastic bag protecting the tying machine during shipment can be used as an effective cover when the tying machine is not in use.

4. Remove the box in the twine container shipped with the tying machine containing four casters.

5. Cut the bands securing the base frame of the tying machine to the bottom skid.

6. Lift tying machine off of skid.

7. Using the casters shipped with the tying machine, insert a caster into the caster socket on each leg of the tying machine base frame.

If any problems are encountered, contact your local B. H. Bunn factory representative.

#### POWER REQUIREMENTS

The single-phase, 1/4 hp, 1725 rpm standard motor provided with your tying machine requires an external power source of 115 volts at 60 Hertz. A standard three-prong electrical cord is provided with the electrical motor. If a three-prong

Upon request, optional electrical motors are available to meet specific power requirements. A convenience outlet for the electrical power cord should be installed at the working location(s) to reduce the hazard of tripping over the cord. When installed the convenience outlet must meet all the electrical standards and wiring color codes for your geographical area.


#### TYING MATERIALS

The tying machine is adaptable to a wide range of tying materials ranging from natural fibre twines to synthetics which can replace wire and strapping in a great many applications. Be sure that the twine being used is of the proper type for the tying application. The right Bunn tying twine can improve production up to 50 percent because it has been tested and approved for use on your machine. It runs through the machine smoothly. Bunn Twine is of uniform size and strength and is free of knots and irregularities that snag and break. It is super-strong and fray-resistant, with minimum linting eliminating twine-snagging and breaking. A free sample folder showing actual twine samples and specifications is available through your local B. H. Bunn factory representative or the B. H. Bunn Company.

The twine cone pilot assembly will hold up to a 10-pound cone of twine. The base diameter of the cone must not exceed 9 inches. Conversion kits are available through your B. H. Bunn Company factory representative when and if it ever becomes necessary to change to a different tying material.

you should become familiar with the threading sequence at this time. Complete threading of the tying machine can be avoided if the end of the twine being used is caught before it passes through the quill shaft. This is accomplished by simply tying the end of the existing twine to the starting

subsequent procedures. It is important to observe the various openings which are identified by numbered labels affixed to the machine through which the twine is to be threaded. Never thread machine while motor is operating.



1. Place power switch in "OFF" position.

2. REMOVE ELECTRICAL CORD FROM POWER RECEPTACLE.

3. Position cone of twine over the cone pilot assembly. Press firmly until seated on foam pad.

#### NOTE

Check proper adjustment of twine cone pilot assembly by moderately trying to turn cone of twine. If movement is encountered, turn wing nut on top of twine cone pilot assembly until cone of twine is secured by the twine cone pilot assembly.

4. Grasp starting end of twine and pull approximately 5 to 6 feet of twine through large round hole at bottom of bracket tension device labeled No. 1.





5. Gently pull tension spring back and thread:


Twine Through bracket tension device small round hole.

#### NOTE

The hole is identified by Number 2 Label.


6. Release tension spring making sure twine is positioned under center of tension spring.





Make sure that appropriate tension spring is installed before proceeding with the threading of the tying machine. It is recommended that a threading tool which may be purchased from your local Bunn factory representative be used to perform steps 7 and 8.

7. Insert twine through quill shaft labeled No. 3.





8. Fish twine out from quill shaft labeled No. 4. After twine is free, thread twine through ring guide labeled No. 5 on twine arm.



9. Pull twine through backside of draw back lever opening labeled No. 6 and then down through ring guide labeled No. 7 at bend in twine arm.

10. Continue to thread twine through twine arm tip labeled No. 8. Pull twine over to the right side of tying machine and press back stringholder release lever. Place twine under stringholder button shaft labeled No. 9, pull up and over shaft and release stringholder release lever. Pull twine taut and press knife trap toward front of tying machine to cut off excess twine.





1. TURN MASTER SWITCH TO THE "OFF" POSITION.
2. Check tying machine threading sequence.
3. Check twine cone for proper positioning over cone pilot assembly.
4. Check of twine cone is properly seated on foam pad.
5. Check twine running tension by pulling twine from end of twine arm assembly. A smooth easy running tension should be felt.
6. Check proper adjustment of twine cone pilot assembly.
7. Visually check tying machine for any mechanical defects or missing parts.
8. Verify that electrical power cord is inserted into receptacle and then set power switch to the "ON" position.

1. Stand at operator's position-front of the tying machine.
2. Position power switch located on the left-hand side of tying machine to the "ON" position.
3. Hold ends of package between thumbs and forefingers of both hands and position package on tying machine table so that right side of package is butted against standard or notch in front table (Figure 1) and positioned over gap between front and back tables.
4. Momentarily depress foot pedal holding package firmly until tying cycle is completed. The tying cycle is completed after the twine arm makes the required wrap.

#### NOTE

The tying machine automatically compensates for the size and shape and the different lengths of twine required. The tying machine also automatically applies the correct amount of tension, ties the patented slipproof and tamperproof knot and then cuts the twine.




Figure 1. Positioning Package for Tying

6. Remove package from tying machine.
7. Repeat steps 3 through 6 above for each package to be tied.
8. After all packages have been tied, set power switch to "OFF" position.

#### AFTER OPERATION PROCEDURES



1. Check remaining supply of twine. If supply is low tie the end of the existing twine to the starting end of the new twine with a square knot.
2. Clean any lint that may have collected in string-holder casting hole. A small pair of tweezers can be used for this purpose.
3. Steam clean and wipe tying machine dry at the end of each normal daily working period.
4. Lubricate tying machine in accordance with Table of Lubrication Requirements.
5. Cover tying machine with plastic bag used to ship tying machine.

The following paragraphs provide maintenance instructions and maintenance function schedules. Maintenance responsibility of the tying machine should be assigned to the maintenance mechanic or other authorized personnel.

A good preventive maintenance program is a major step forward to assure trouble-free tying machine operation. In order to be effective, routine inspection, lubrication, and adjustment schedules must be established and followed. The following Table Preventive Maintenance Checks and Services and Table of Lubrication Requirements is provided for tying machines subjected to normal usage which is considered to be approximately 30 hours of operation weekly. Substantial deviations from normal usage should require an adjustment in the indicated frequencies. Frequencies established in the Table of Preventive Maintenance Checks and Services are: Daily (D), Monthly (M), and every third month (Q). The Table of Lubrication Requirements has frequencies of daily and weekly. The tables should be copied for use by maintenance personnel, to facilitate checking off each item as it is performed. These lists can then be signed and dated to serve as an accurate record of preventive maintenance work performed. Deviations from normal tying machine usage should become a part of the records for the tying machine.

CHECK OR SERVICE ITEM	FREQUENCY		
	D	M	Q
<b>ELECTRICAL COMPONENTS</b>			
1. Check electric power cord and plug. Cord should not be frayed and should be securely fastened. Plug should not be faulty.		X	
2. Check electric motor assembly, especially breather vents, which should be free of dirt and foreign particles.		X	
3. Operate electric motor assembly and listen for abnormal noises.	X		
4. Check condition of power switch to verify that it is securely mounted and operating properly.	X		
<b>MECHANICAL COMPONENTS</b>			
1. Operate tying machine and observe that it ties a bundle or package correctly.	X		
2. Remove lint and loose twine from stringholder button holes using a small pair of tweezers.	X		
3. Check twine running tension. Readjust twine tension spring if necessary.		X	
4. Check condition of knife. Knife should be sharp and free of knicks. Replace if necessary.	X		
5. Check for proper position of star wheel and shaft assembly gear and observe gear for excessive wear. Replace if necessary.		X	
6. Check for cracked or broken teeth on gears and sprockets and main gear. Replace as required.			X
7. Check condition of v-belt for evidence of fraying. Replace if required.		X	
8. Check for loose pins and set screws in gears.			X
9. Check entire tying machine for loose hardware. Tighten loose hardware as required.	X		
10. Check for broken or weak knotter flat springs and weak tension. Replace as required.	X		

LUBRICATION ITEM	FREQUENCY	
	DAILY	WEEKLY
<p align="center"><b><u>NOTE</u></b></p> <p>Apply several drops of SAE 10 oil or equivalent unless otherwise specified. If necessary, refer to the exploded views in the parts list section of this manual for assembly part nomenclature</p>		
<b>KNOTTER HEAD ASSEMBLY</b>		
1. Oil cup (Knotter Head Pivot).	X	
2. Two oil holes (encircled in red on Knotter Head Sub-assembly).	X	
3. Oil hole (encircled in red on Star Wheel and Moter Gear Assembly).	X	
4. Between knotter lever and knotter head subassembly.		X
5. Around diameter of knotter roller.		X
6. Knotter lock plunger.		X
<b>STRINGHOLDER AND KNIFE TRAP ASSEMBLY</b>		
1. Between knife trap rivet and knife trap lever assembly.	X	
2. Between knife trap shoulder screw and knife trap lever assembly.	X	



## MAIN TABLE ASSEMBLY

1. Around diameter of drawslide lever assembly roller.
2. Between washer and drawslide lever assembly.
3. Between drawslide lever assembly and main table subassembly.
4. Into three oil holes (encircled in red on Main Table Sub-assembly).
5. Between stripper and main table subassembly so that stripper pivot pin is lubricated.

X

X

X

X

X






Figure 4. Main Table Lubrication Diagram



**NOTE**

Apply a liberal coat of recommended lubriplate  
to the following unless otherwise specified.

**DRIVE ASSEMBLY**

- |  |   |   |
|--|---|---|
| 1. Knotter rack assembly cam surface and teeth.  |   | X |
| 2. Cam riser cam surface.  |   | X |
| 3. Cam switch cam surfaces.  |   | X |
| 4. Apply several drops of SAE 10 oil to chain gear oil hole (encircled in red on machine).       |   | X |
| 5. Apply several drops of SAE 10 oil to the oil cup(s) located at the rear of the tying machine. | X |   |
| 6. Clutch fork pivot pin.  | X |   |
|  | X |   |











Figure 6. Drive Assembly Lubrication Diagram

troubles which may develop in the tying machine. The tying machine is generally trouble free. However, the tying machine suffers the usual wear and misadjustment from normal use. Careful inspection and accurate analysis of the symptoms listed in the Table of Troubleshooting Information will



cies that may occur, therefore, if a specific trouble is not covered herein, proceed to isolate the major component in which the trouble occurs and then isolate and correct the trouble.

TABLE OF TROUBLE SHOOTING INFORMATION

TROUBLE	POSSIBLE CAUSE	CORRECTIVE ACTION
<p>a. Tying machine will not operate with power switch set to "on" position.</p>	<p>Electric power cord not plugged into receptacle.</p> <p>Circuit breaker tripped.</p> <p>Broken or disconnected circuit wire.</p> <p>Faulty power switch.</p>	<p>Plug electric power cord into receptacle.</p> <p>Reset circuit breaker. If circuit breaker trips again, inspect and test for short in tying machine circuit or electric power cord. Correct defect as required.</p> <p>Repair or replace broken wire.</p> <p>Replace defective power switch.</p>
<p>b. Twine breaks frequently in stringholder button.</p>	<p>Improper twine.</p> <p>Excessive stringholder button tension.</p>	<p>Use proper size of twine.</p> <p>Readjust stringholder button pressure.</p>
<p>c. Half or single loop on knot</p> 	<p>Piece of twine wrapped around stringholder button shaft relieving tension on twine (or tape).</p>	<p>Depress and hold button release lever and remove bits of twine using a small pair of tweezers. Then release button release lever.</p>
<p>d. One loop knot that slipped out.</p> 	<p>Excessive twine running tension.</p>	<p>Readjust to decrease twine running tension.</p>

<p>e. One long and one short loop.</p> 	<p>Improper twine.</p> <p>One loop catching in back of knotter throat, improper knotter release adjustment.</p>	<p>Use proper size of twine.</p> <p>Readjust knotter release.</p>
<p>f. Break in twine in front of knot.</p> 	<p>Friction along twine path.</p>	<p>Remove sharp edges from twine path in twine tension plate assembly, twine bracket, quill shaft, twine arm hub, twine arm assembly ring guides, drawback lever, and twine arm tip.</p>
<p>g. Ragged ends of twine at knot.</p> 	<p>Dull or knicked knife.</p>	<p>If knife is excessively knicked, replace. If knives continue being knicked, lubricate knife trap pivot points to assure that knife trap does not stick, allowing knife to remain in path of drawslide.</p>
<p>h. Loose knot and loops slightly shorter than normal.</p> 	<p>Loops release from knotter too soon, improper knotter release adjustment.</p> <p>Stripper too short.</p>	<p>Readjust knotter release.</p> <p>Replace stripper.</p>
<p>i. Short loops and tight knot.</p> 	<p>Improper balance between twine running tension and stringholder button pressure.</p>	<p>Check stringholder button pressure. Readjust twine running tension.</p>




<p>j. Cut loop ends.</p> 	<p>Stripper points shearing against side of knotter jaws when stripping.</p>	<p>Readjust stripper shear action, bend top front end of stripper down tapping with a light hammer.</p>
<p>k. Very short loops and long ends.</p> 	<p>Knot slipping by stripper. Improper gap between stripper point and knotter.</p> <p>Knottter flat springs broken or weak.</p>	<p>Realign stripper point and knotter.</p> <p>Replace knotter flat springs.</p>
<p>l. Twine catches in stripper.</p>	<p>Stripper spring broken or weak.</p>	<p>Replace stripper spring.</p>
<p>m. Twine pulls out of stringholder button.</p>	<p>Twine improperly threaded.</p>	<p>Check stringholder button threading and rethread if necessary.</p>

## Section VI / PARTS LIST

The tying machine is identified by the model number and serial number stamped on the name plate located on the left side frame of machine. Be sure to use both the model number and serial number when requesting part information or when ordering replacement parts. Using the complete equipment identifier (model number and serial number) will

ensure receipt of proper replacement part(s). Use only genuine B.H. Bunn tying machine parts. These parts are identified by the B.H. Bunn trademark stamped on the part. Substitution parts may cause erratic and/or abnormal tying cycle operation.


USE COMPLETE IDENTIFIER (MODEL AND SERIAL NUMBER) WHEN ORDERING ALL REPLACEMENT PARTS



Index Number	Part Number	Description	Number Required	Index Number	Part Number	Description	Number Required
—	008 067	Main Table Assembly	1	17	100 121	Screw-Set, socket head, cup point, 8-32 x 1/4 in long	1
1	100 135	Washer-Split Lock 1/4 in.	2	18	100 084	Screw-Knotter release adjusting	1
2	081 014	Riser Lever Stud	1	19	100 191	Nut-Jam-Hex, 1/4-28NF	1
3	100 104	Screw-Fillister head, slotted 1/4-20 NC x 1 in. long	2	20	081 056	Stud-Knotter release	1
4	100 158	Pin-Groove, 3/16, dia. x 1 in. long, Drawslide Spring	1	21	100 591	Stud-Knotter head stop	1
5	088 066	Main Table Sub-Assembly, Note 1.	1	22	083 079	Guide-Riser pin	2
6	045 020	Drawslide Assembly and Cap. Note 2.	1	23	100 597	Screw-Round head, self tap 10-24 NC x 3/8 in. long	1
7	074 059	Spring-Drawslide	1	24△	032 128	Tip-Up Assembly	1
8	032 127	Riser Liver	1	25△	052 —	Stripper	1
9	100 124	Screw-Set, square head, half dog point, 1/4-20 NC x 1 in. long.	1	26△	083 085	Pin-Stripper pivot	1
10	100 150	Nut-Hex, 1/4-20 NC	2	27△	074 035	Spring-Stripper	1
11	100 098	Screw-Round head 10-24 NC x 3/8 in. long	1	28△	083 053	Pin-Riser	1
12	100 131	Washer-Flat 1/2 o.d. x 7/32 i.d. x 3/64 in thk.	1	29	081 013	Stud, Drawslide Lever	2
13	032 132	Drawslide Lever Assembly	1	30	070 065	Cap, Drawslide Assembly	1
14	100 067	Washer-Drawslide Lever	1	31	100 372	Pin-Roll, 1/8 dia. x 3/4 in.	1
15	100 110	Screw-Flat head, slotted 1/4-20 NC x 1/2 in. long	1	32	100 615	Screw-Hex head 5/16-18 NC 1-1/4 in. long	2
16	100 596	Screw-Set, square head, cup point, 1/4-20 NC x 3/4 in. long	1	33	100 185	Shim-Main Table	2
				34	100 273	Screw-Hex head 5/16 x 18 NC x 3/4 in. long, "Whiz-Loc"	1
				35	100 134	Washer	1
				36	100 566	Screw	1
				37	025 288	Bracket Drawslide Spring	1


\* Specify Type Twine Being Used — △ Not Part of Assembly, Order Separately  
NOTE: 1. Sub-Assembly includes Items 2, 4, 10, 19, 20, 21, 22, 29 and 31.

USE COMPLETE IDENTIFIER (MODEL AND SERIAL NUMBER) WHEN ORDERING ALL REPLACEMENT PARTS




Index Number	Part Number	Description	Number Required	Index Number	Part Number	Description	Number Required
1	017 — 017 094	Knotter Head Assembly Knotter Head Sub-Assembly. Note	1 1	13	100 009	Screw-Knotter Lever	1
2	013 085	Knotter Head Roller	1	14	100 143	Nut-Hex, 10-24 NC	1
3	100 528	Nut Nylock	1	15	100 120	Screw-Set, socket head, cup point, 10-32 NF x 5/16 in. long	1
4	020 156	Star Wheel & Miter Gear Assembly	1	16	100 574	Fitting Hydraulic	1
5	082 003	Plunger-Knotter lock	1	17	017 —	Knotter Body & Miter Gear Assembly	1
6	074 006	Spring-Knotter lock	1	18△	011 004	Pivot Assembly-Knotter Head	1
7	100 187	Screw-Set, half dog point, 1/4-20 NC x 1 in. long	1	19△	100 275	Screw-Hex head cap, 5/16- 18 NC x 3-1/4 in. long	1
8	100 150	Nut-Jam-Hex, heavy 1/4-20 NC	1	20△	100 287	Nut-Flange lock, large 5/16- 18 NC	1
9	074 013	Spring-Flat knotter	2	21	100 575	"O" Ring	4
10	100 131	Washer-Flat No. 10	1	22	100 576	"O" Ring	2
11	100 092	Screw-Round head, 10-24 NC x 1 in. long	1	23	100 571	Spacer "O" Ring	1
12	032 068	Lever-Knotter	1	24	100 062	Cover-Ball Valve Oil Hole	3

\* Specify Type Twine Being Used    △ Not Part of Assembly. Order Separately




Index Number	Part Number	Description	Number Required	Index Number	Part Number	Description	Number Required
1	030 144	Stringholder and Knife Trap Assembly	1	14 *	021 002	Knife	1
2	030 142	Stringholder and Pins Sub-Assembly	1	—	021 009	Knife, Package of 10	
3	030 029	Button-Stringholder	2	15△	100 356	Screw-Binder head, 8-32 NF x 1/4 in. long	1
4	100 610	Screw 10-32 x 3/8	1	16△	100 565	Screw Socket Head Cap	1
5	074 041	Spring	2	17△	100 081	Screw-Knife Trap Shoulder	1
6	100 144	Nut-Hex, 10-32 NF	1	18	030 084	Slide-Lever	1
7	100 033	Washer-Stringholder Button	1	19	030 083	Pivot	1
8	032 157	Lever-Button Release	1	20	100 088	Screw-Pivot	1
9	100 010	Screw-Button Release Lever	1	21△	030 085	Angle	1
10	032 159	Knife Trap and Lever Assembly	1	22△	030 086	Link	1
11	100 562	Screw-Knife Trap	2	23△	100 425	Nut-Hex Lock No. 12-24 NC	1
12	100 607	Nut-Hex	1	24△	100 187	Screw-Set, half dog point, 1/4 x 20 NC x 1 in. long	1
13	074 033	Spring-Knife Trap	1	25△	100 188	Nut-Hex, 1/4 x 20 NC ESNA	1
				26	100 158	Spring Pin	1
				27	100 569	Groove Pin	2

\* Specify Type Twine Being Used — △ Not Part of Assembly. Order Separately.



Index Number	Part Number	Description	Number Required	Index Number	Part Number	Description	Number Required
1	009 112	Main Cam Assembly (0°)	1	9	100 095	Screw-Machine, flat head, No. 10-24 NC x 5/8 in. long	4
2	009 101	Cam Wheel, (0°) Note 1.	1	10	100 128	Screw-Square Head	1
3	009 060	Switch-Knotter Head Cam	1	11	100 326	Screw-Machine flat head No. 10-24 NC x 7/8 in. long	2
4	100 399	Screw-Socket head, cap, 1/4-20 20 NC x 5/8 in. long	2	12	009 120	Riser Cam	1
5	020 072	Rack-Knotter Cam. Note 1.	1	13	009 063	Clutch-Kickout Block	2
6	009 113	Cam Drawslide	1 set	14	100 372	Roll Pin	1
7	100 102	Screw-Machine, flat head, No. 12-24 NC x 3/4 in. long	2	15	100 160	Groove Pin 3/16 x 7/8 in. long	1
8	100 328	Screw-Machine flat head, No. 12-24 NC x 5/8 in. long	2	16	100 161	Groove Pin 3/16 x 1 1/2 in. long	1
				17	100 127	Screw, Square Head	

NOTE: Item 2 Includes Knotter Head Cam Switch.



USE COMPLETE IDENTIFIER (MODEL AND SERIAL NUMBER) WHEN ORDERING ALL REPLACEMENT PARTS


Index Number	Part Number	Description	Number Required	Index Number	Part Number	Description	Number Required
1	084 056	Main Table Support and Kickout Assembly	1	11△	100 450	Screw-Hex Head, 1/4-20 NC x 1 in. long	1
2	032 081	Lever-Clutch Kickout	1	12△	100 286	Nut-Flanged Hex, 1/4-20 NC	3
3	100 078	Screw-Trip Rod	2	13	100 503	Groove pin, 3/16 dia. x 1 1/2 in.	1
4	100 151	Nut-Hex, 1/4-28 NF	2	14△	100 273	Screw-Hex, Head, 5/16-18 NC x 3/4 in. long "Whiz-Loc"	2
5	100 135	Washer-Split Lock, 1/4	1	15	011 034	Trip Extension	1
6	074 055	Spring-Trip Return	1	16	074 050	Spring-Trip Cable	1
7	011 019	Bell Crank and Kickout Wedge Trip Assembly. Note 1.	1	17	100 238	Screw-Hex 1/4-20 x 1 1/4 in. long	1
8	100 306	Screw-Socket Set Oval Point, 1/4-20 NC x 1 1/4 in. long	1	18	100 158	Groove Pin 3/16 dia. x 1 in. long	1
9	011 022	Trip Cable-Clutch	1				
10	084 055	Main Table Support Sub-Assembly. Note 2.	1				

△ Not Part of Assembly. Order Separately

NOTE: 1. Includes Item 13. —2. Includes Items 8, 12, 13 and 17


## Parts List

## TWINE ARM & DRAWBACK LEVER ASSEMBLY




USE COMPLETE IDENTIFIER (MODEL AND SERIAL NUMBER) WHEN ORDERING ALL REPLACEMENT PARTS

Index Number	Part Number	Description	Number Required	Index Number	Part Number	Description	Number Required
—	041 296	Twine Arm and Drawback Lever Assembly	1	9	135 027	Chain-Twine Arm Drive	1
1	100 040	Screw-Drawback Lever	1	10	135 049	Link-Master	1
2	032 121	Drawback Lever Assembly	1	11	100 136	Washer, Lock	1
3	100 501	Nut	1	12	100 235	Pin, Retaining #0 x 3/8 in. long	1
4	100 110	Screw-Machine, flat head, No. 1/4-20 x 1/2 in. long	2	13	100 157	Pin Grove 3/16 x 1 1/4 in. long	1
5	100 039	Washer-Bearing Retainer	1	14	020 008	Transfer Gear Assembly	1
6	013 065	Bearing Ball	1	15	100 017	Oil Cup	1
7	034 013	Housing and Gear Assembly	1	16	074 018	Spring Drawback Lever	1
8	013 064	Bearing Ball	1				



Index Number	Part Number	Description	Number Required	Index Number	Part Number	Description	Number Required
1	019 073	Clutch Assembly	1	16	100 294	Pin-Spirol 3/16 dia. x 1 3/4 in. long	2
2 <sup>△</sup>	025 238	Bracket Assembly, Clutch Fork Pivot	1	17	013 099	Bearing-Clutch	1
3 <sup>△</sup>	100 239	Screw-Hex head, 5/16-18 NC x 5/8 in. long. "Whiz-Loc"	7	18	012 145	Shaft-Single Clutch	1
4 <sup>△</sup>	100 284	Nut-Hex, 5/16-18 NC "Whiz-Loc"	10	19	020 216	Pinion-Clutch Shaft	1
5	094 035	Collar-Clutch Shaft	3	20	100 497	Pin	1
6	074 004	Spring-Clutch (Export only)	1	21 <sup>△</sup>	013 089	Bearing-Clutch Shaft	2
6A	074 003	Spring-Clutch (Domestic only)	1	22 <sup>△</sup>	013 091	Bearing Flangette	4
7	024 016	Clutch Member-Outer	1	23	083 075	Groove Pin 3/16 x 1 1/4 in. long	1
8 <sup>△</sup>	071 001	Fork-Clutch	1	24	024 014	Clutch Member-Inner	2
9 <sup>△</sup>	064-031	Roller-Clutch Fork	1	25	100 406	Screw-Hex head 5/16-18 x 1 in. long	3
10 <sup>△</sup>	100 072	Screw-Clutch Fork Roller	1	26	126 075	Spacer Thrust Plate	3
11 <sup>△</sup>	100 297	Hitch-Pin No. 13	2	27	130 189	Thrust Plate	1
12 <sup>△</sup>	083 006	Pin-Clutch Fork Pivot	1	28	024 022	Disc	1
13	019 095	Pulley, Grooved	1	29	094 032	Collar-Clutch Shaft, Adjustable	1
14	024 003	Clutch Disc	2	30	094-030	Thrust Coller Clutch	1
15	100 181	Drive Screw Round head No. 12 x 5/8 in. long	6	31	100 601	Pin Rolled 3/16 x 7/8	1


<sup>△</sup> Not Part of Assembly. Order Separately.



Index Number	Part Number	Description	Number Required	Index Number	Part Number	Description	Number Required
1	012 132	Main Shaft	1	12	020 212	Sprocket-Chair Drive	1
2	083 005	Key-Cam Wheel	1	13	020 214	Elliptical Gear (upper)	1
3	083 090	Key-Main Gear	1	14	100 344	Shim-Chain Gear Assembly	1
4	020 215	Elliptical Gear (lower)	1	15	013 048	Bearing-Gear	1
5	100 262	Screw-Socket Set Knurled, cup point, 5/16-18 NC x 3/8 in. long	4	16	013 090	Bearing-Main Shaft	2
6	126 071	Spacer-Elliptical Gear (to rear bearing)	2	17	013 092	Bearing Flangette-Main Shaft	4
7	020 217	Main Gear	1	18	100 259	Screw-Socket Set-Knurled Cup Point, 1/4-28 NF x 1/4 in. long	4
8	100 128	Screw-Square Head Set	1	19	126 070	Spacer-Main Cam Assembly (to front plate)	1
9	020 213	Chain Gear Assembly	1	20	083 091	Key-Elliptical Gear (lower)	1
10	081 077	Stud Assembly-Chain Gear Pivot	1	21	100 239	Screw-Hex Head 5/16-18 NC x 5/8 in. long "Whiz-Loc"	6
11	100 268	Screw-Flat Head Socket Cap, 1/4-20 NC x 1-1/4 in. long	2	22	100 284	Nut-Hex 5/16-18 NC, "Whiz-Loc"	6
				23	100 227	Screw-Square Head Cup Pt.	1



AND SERIAL NUMBER) WHEN ORDER-  
ING ALL REPLACEMENT PARTS



2	132 212	Ring Guard	2	43	126 006	Spacer-Torrington Bearing	1
3	132 213	"U" Brace Guard, Twine Arm	1	44	013 016	Race	
4	132 214	Top Brace Center Guard, Twine Arm	1	45	130 207	Support - Motor Plate	1
5	038 117	Door Panel	1	46	100 101	Screw, 10-32 x 1/2 in. long, Round Head	2
6	094 002	Collar - Quill, Twine Arm	1	47	100 105	Screw, 1/4-20 x 3/4 in. long, Truss Head	7
7	010 095	Loose Table Assembly	1	48	100 107	Screw, 1/4-20 x 5/8 in. long, Hex Head	3
8	007 090	Trough Assembly	1	49	100 111	Screw, 1/4-20 x 1/2 in. long, Truss Head	14
9	037 034	Shield - Clutch	1	50	100 239	Screw, 5/16-18 x 5/8 in. long, Hex Head - "Whiz-Loc"	7
10	126 056	Spacer - Clutch Shield	4	51	100 255	Screw, 8-32 x 1/2 in. long, Pan Head	2
11	081 085	Tube Cap	2	52	100 256	Screw, 1/4-20 x 3/4 in. long, Hex Head Flanged - "Whiz-Loc"	8
12	025 240	Lever - Knife Trap, Release	1	53	100 273	Screw, 5/16-18 x 3/4 in. long, Hex Head - "Whiz-Loc"	12
13	069 038	Channel - Front Plate Support	1	54	100 284	Nut, 5/16-18 Hex "Whiz-Loc"	23
14	132 219	Guard - Rear	1	55	100 286	Nut, 1/4-20 Hex "Whiz-Loc"	10
15	132 187	Guard - Rear End	1	56	100 289	Welnut Fastener - J1032	4
16	025 350	Bracket Twine Holder	1	57	100 379	Screw, 1/4-20 x 1 1/2 in. long, Hex Head	2
17	070 075	Twine Cone Pilot	1	58	100 481	Screw, 10-32 x 1 in. long, Oval Head	4
18	081 071	Stud - Twine Cone Pilot	1	59	100 482	Washer # 10 Countersunk	4
19	077 016	Pad - Twine Cone	1	60	100 564	Screw, 8-32 x 1/2 in. long, Hex Head Flanged - "Whiz-Loc"	2
20	100 145	Nut - Knurled Brass - No. 12-24 NC	1	61	100 572	Oval Head Slotted Stud	7
21	074 001	Spring - Tension	1	62	100 573	Receptacle Assembly	7
22	025 239	Bracket Tension Device	1	63	100 577	Screw, 5/16-18 x 2 in. long, Hex Head	2
23	100 410	Screw - Tension Holder	1	64	100 581	Nut, 1/4-20 Hex - Acorn	10
24	130 181	Tension Device Assembly	1	65	100 582	Nut, 5/16-18 Hex - Acorn	2
25	050 189	Box - Switch, Watertight	1	66	126 055	Spacer	2
26	050 190	Switch & Cover Assembly	1	67	100 279	Fender Washer	3
27	050 194	Cord Set Assembly with Switch	1	68	100 565	Screw, 5/16-18 x 1 1/4 in. long, Socket Head Cap	2
28	025 241	Foot Pedal Mounting Bracket Assembly	2	69	100 537	Nut, 5/16-18 Hex Flanged "Whiz-Loc"	8
29	100 320	Grommet - Plain Bore Rounded	2	70	100 127	Screw, 5/16-18 x 1 1/2 in. long, Square Head	2
30	059 033	Foot Pedal	1				
31	011 022	Trip Cable - Clutch	1				
32	100 303	Tubing Clamp	1				
33	132 215	Guard - Foot Pedal	1				
34	040 006	V-Belt	1				
35	019 091	Motor Sheave (115V - 60HZ)	1				
35A	019 100	Motor Sheave (22V - 50HZ)	1				
36	039 034	Motor (115V - 60HZ)	1				
36A	039 033	Motor (220V - 50HZ)	1				
37	038 115	Panel - Front	1				
38	038 113	Panel - Side	2				
39	135 063	Caster - Socket	4				
40	135 062	Caster with Side Brake	4				
41	100 023	Washer	1				

USE COMPLETE IDENTIFIER (MODEL  
AND SERIAL NUMBER) WHEN ORDER-  
ING ALL REPLACEMENT PARTS



# NOTICE

**DO NOT ATTEMPT TO OPERATE  
THIS EQUIPMENT BEFORE READING  
THE OPERATION INSTRUCTIONS  
AND PERFORMING THE BEFORE  
OPERATIONS CHECKS PARAGRAPH  
IN SECTION 3 OF THIS MANUAL**

## OPERATOR SAFETY REMINDERS

The National Safety Council reminds us that most accidents are caused by the failure of some individual to follow simple and fundamental safety rules or precautions. For this reason, you, as a careful operator, are the best insurance against an accident.

Regardless of the care used in the design and construction of any type of equipment there are many conditions that cannot be completely safeguarded against without interfering with reasonable accessibility and efficient operation.

- NEVER ATTEMPT TO THREAD, CLEAN, OIL OR ADJUST A MACHINE WHILE MOTOR IS OPERATING OR MACHINE IS IN MOTION.
- NEVER OPERATE MACHINE WITH ANY GUARD OR PANELS REMOVED AND KEEP HANDS AWAY FROM INSIDE OF GUARD TO AVOID BEING STRUCK BY TWINE ARM.
- DO NOT REMOVE GROUNDING PRONG FROM POWER CORD.