


Maintenance Manual and Parts Catalog



BUNN

PACKAGE TYING MACHINES
for over half a century

B. H. BUNN COMPANY

7605 Vincennes Ave., Chicago, Illinois 60620
Telephone: Area Code 312 • 483-3222

B. H. BUNN INTERNATIONAL, LTD.

7605 Vincennes Ave., Chicago, Illinois U.S.A. 60620
CABLE ADDRESS "BUNNTYCO"

NEW ADDRESS & TELEPHONE:

12550 S. Lombard Lane, Alsip, Ill. 60658
Area Code 312 • 388-7600

NEW ADDRESS:

12550 S. Lombard Lane, Alsip, Illinois, U.S.A. 60658

Maintenance Manual & Parts Catalog

BUNN **PACKAGE TYING** MACHINES

Table of Contents	Page
How to identify the main assemblies	1
Threading instructions	2
Correct operating procedure	3
One way wraps	3
Cross ties	3
How to avoid problems	4
How to:	
replace drive belt	4
replace stripper spring	4
replace the stripper	4
replace the knotter	5
correct clutch slipping	5
clean the clutch	5
correct automatic tripping	5
The knot tells the story	6 & 7
Complete list of parts	8, 9, 10, 11 & 12
Exploded views and parts listings:	
Knotter head assembly	7 & 12
Main table assembly	13
Main table assembly, post office	13
Main table assembly, clamp model	13
Stringholder assembly	7 & 14
Cam wheel, clutch & chain gear assemblies	15
Double clutch assembly	15
Post Office pressure trip	15
Twine arm assembly	16
Base parts	17
Illustrations and model numbers of other Bunn machines	18




Note:


When ordering parts, please give the serial number of your Bunn Tying Machine. You will find it on the name plate on the right side panel of the machine.

How to identify the main assemblies


MAIN TABLE ASSEMBLY




KNOTTER HEAD ASSEMBLY




STRINGHOLDER ASSEMBLY





CAM WHEEL, CLUTCH & CHAIN GEAR ASSEMBLIES



BASE PARTS



TWINE ARM ASSEMBLIES



Installation and Operation

The Bunn Package Tying Machine is shipped to you crated. Uncrate your machine and cut the twine holding the twine arm to the central shaft. Attach the guard which you will find in the crate with the machine.



Threading Instructions





Before the machine is shipped it is threaded through each guide from the twine can to the stringholder button. Please note the various openings through which the twine passes so that the subsequent threadings may be simplified. A quantity of rock wool in the bottom of the can prevents twine from tangling under the cone and should remain in the container.



1. TURN switch to "OFF" position. (Machine is now ready to thread.)
2. RAISE twine from end of "CONE" to hole "A" in bracket, directly above cone.
3. PULL twine thru hole "A" to hole "B" in "TENSION BRACKET."
4. PUSH twine thru hole "B."
5. PULL twine upward and behind flat spring on tension bracket covering hole "B."
6. PUSH about eight inches of twine into hole "C."
7. BLAST air into hole "C" until twine "POPS" out at hole "D."
8. PULL twine thru eyelet "E."
9. RAISE twine to hole "F" at end of draw back lever arm.
10. PULL twine thru hole "F" and eyelet "G."
11. PUSH twine thru hole "H" at end of twine arm.
12. PULL twine under and around button "I" and hold with left hand.
13. PULL twine tightly with left hand until twine SLIDES INTO CUTTING POSITION.
14. LOWER left hand to rest on work table and PULL twine *tightly*.
15. PULL cutting knife lever handle "J" with right hand until twine is cut.
16. TURN switch to "ON" position. (Machine is now ready for operation.)

NOTE: If the end of the old cone of twine is caught before running out of the machine, the first of the next cone can be tied to it with a square knot. The knot will work through the machine. If the end of twine is not caught as it leaves the cone, the machine may be threaded from the new cone up to any point.

2




Machine Operation

We advise making a thorough study of your machine as it is turned through a complete cycle by hand.

To turn your machine over by hand the following method is suggested:

1. With motor turned off, face the machine from the side on which you find the nameplate and serial number.
2. Press the foot trip. Grasp the large pulley wheel at the top and pull down. With the machine threaded and a package in place, the complete cycle can be observed when hand operated in this manner.
3. Turn on the motor and the machine is ready for use.


CAUTION: Be careful to avoid being struck by the twine arm as it makes a circular revolution.



Correct Operating Procedure

Grasp both ends of bundle between thumbs and forefingers. Press right end against vertical standard and then press foot trip (or on Post Office model press entire bundle down on pressure trip). Hold bundle steady and firmly until tie is complete. (After tie is completed on post office models, quickly pick up bundle before next tying cycle begins. THEN turn bundle to tie the short way and repeat above directions.)


One way wraps




To operate your Bunn Tying Machine to the best advantage, we suggest the following steps for a single, double, or triple wrap one way machine:

1. Standing in front of the machine at the operating position, which is the widest side of the fixed table (hereafter referred to as the trough), hold the package firmly in tying position and step on foot trip.
2. The position of the package should be such that the center is directly over the separation of the trough and the loose table. Also, the right side of the package should be located against the shoulder or groove in the trough.
3. While holding the package firmly with both hands, fingers at side, thumbs on top, step on the foot-trip and remove foot instantly. As soon as the tie is completed, remove the package and you should find a snug, secure package tied with a non-slip knot that will stand even the roughest handling.

Cross ties



For tying packages, boxes, etc., with a cross tie, place the package on the machine for the long-way wrap first. The package need not set against the ledge above the knotter, but rather slightly on top of this ledge. Step on the foot-trip, INSTANTLY removing the foot. The twin arm will make one wrap and come to a stop. Grasp the package, and turn in a clock-wise direction one-quarter of a turn, bringing the right hand toward the body. Set the right-hand side of the package against the ledge, and do not force the package away from the operator, but rather draw it back slightly. This action makes the cross, bringing the string in position for the tip-up to catch it. Holding the package firmly in this position, set the foot-trip once more—INSTANTLY removing the foot. The twine arm will make the final revolutions, and the machine will tie the knot. This is a very simple operation when once it is understood.



How to avoid problems



CAUTION: Never file the face of the stringholder casting! It was filed by a trained workman, and the groove was put there for a purpose, and is not caused by wear. Necessary adjustments can be made by regulating the spring tension.

1. **Threading:** Be sure your machine is threaded properly. This is the major cause of machines not working properly (see threading instructions).
2. **Twine:** Your machine is adjusted for a definite size twine. For best results this should be used at all times.
 - a. Weak twine will cause trouble, as it will break at the stringholder button instead of pulling out smoothly.
 - b. If the twine is too large it will not be released by the knotter jaws.
 - c. If the twine is too small it will cause a loose knot.
3. **Stringholder Button:** If you are using the proper size and a good grade of twine, and it breaks frequently, leaving short pieces behind the stringholder button, this is usually caused by too much spring pressure on the button. This can be remedied by loosening the two lock nuts, with washer between, that regulate the spring tension.
4. **Stringholder Button Adjustment:** Keep the stringholder button free of broken bits of twine. If there is a small piece of twine wrapped around the shaft of the stringholder button this will take the tension from the end of the twine, permitting it to jerk out or pull part way back into the button at the time the arm starts its revolution, causing a half or single loop knot

to be formed. Use the lever attached to the side of the stringholder button for releasing the tension and removing small bits of twine from this unit.

5. **Clean Stringholder Button:** After a period of use the hole in the stringholder casting may become filled with lint. A small pair of tweezers can be used to clean out this material.

CAUTION: Do not use a sharp instrument to force the button open. Always use the release lever!

6. **Twine Running Tension:** A smooth, easy running tension is always the best. Neither too tight nor too loose. This can be tested by pulling a quantity out from the end of the twine arm. The adjustment for running the tension is the flat spring held in place by two knurled brass nuts at the back of the machine. If the tension is too tight these should be loosened approximately one-half turn at a time, until the proper tension is made. If the tension is too loose they should be tightened one-half turn at a time until the tension is correct.
7. **Single Loop Knots:** If your machine is making a one-loop knot that always slips out, it is possible that the running tension is too tight, and the tension should be loosened until a double-loop knot is formed. This adjustment can be made as outlined in No. 6.
8. **Cutting Knife:** When the knife becomes dull it can be replaced by removing the screw that holds it in place and inserting a new knife, or the edge can be sharpened by grinding a small quantity off the cutting edge on a grinding wheel or hand stone.

...but just in case you
do have a problem,
here's how to:

4

replace the drive belt

1. Remove clutch fork No. 63 located just above motor by removing the clutch fork pivot pin No. 66.
2. Remove the two cap screws that hold the lower bearing No. 67 to the side frames and remove lower bearing (do not pull clutch out).
3. Slip belt over clutch and re-assemble lower bearing.
4. Re-assemble clutch fork No. 63 and clutch fork pivot pin No. 66, making sure the clutch block lever No. 112 fits into the slot of the clutch fork. (See page 15.)

replace the stripper spring

If the twine continually catches in the stripper No. 52, it may mean that the spring that operates the stripper is broken or has lost its tension.

1. Remove sheet metal trough from main table.
2. Remove stripper screw No. 53 and remove stripper.
3. Replace stripper coil spring No. 54 and re-assemble. Be sure screw is all the way in. (See page 13).

replace the stripper

1. Remove sheet metal trough from main table.
2. Remove stripper screw No. 53 and remove stripper.
3. Re-assemble with new stripper. The notched face of the stripper should be close to the side of the knotter body when using twine 12-ply and under. When heavy twine, 16- to 24-ply, is used a space of .010" should be allowed between the stripper face and side of knotter body. (See page 13.)

4. Check to see if the notch in the stripper is in line with the point of the knotter as the knotter withdraws from the stripper.
5. Adjustments can be made by bending the stripper. A few taps with a light hammer will normally give the correction needed.

replace the knotter

In replacing the *knotter* in your Bunn Machine, the mechanic must be careful to time the new *knotter* properly. When the *knotter* is timed correctly, the two *taper pins* in the *bevel gears* should be parallel to each other, with the *knotter roller* at the bottom of the *cam*. In other words, when the *knotter* is pointing straight ahead.

Note the position of the teeth on the *star wheel*. You will see that the *star wheel* contains seven uniform teeth and one slightly beveled. When timed properly the beveled tooth will be slightly to the right of the center line — as shown at right. If the *pointed tooth* is not in correct position — remove the *taper pin* and *bevel gear*, located at the end of the *star wheel shaft*, and time correctly.



If knotter holds the loops of the knot, and fails to release after the tying cycle—

1. There is an *adjusting screw* located directly back of the knotter for adjusting the space between the jaws.
2. The *adjusting screw* is set at a 45° angle and is held in positive location by a small hexagon lock nut.
3. By holding the *set screw* in place with a screw driver, the *lock nut* is released and the *set screw* turned in a clockwise direction until the twine is released (usually a quarter turn is sufficient).
4. Then by holding the *set screw* in location with a screw driver, tighten the *lock nut* securely.

correct clutch slipping

1. Your machine is equipped with a dry clutch and no oil should be allowed to get between the clutch plate and the clutch disc, as this will cause the clutch to slip.
2. When oil on the clutch is causing the machine to not operate properly, it is suggested that an oil can containing a solvent be used and a few drops "squirted" between the clutch disc and the clutch plate. This should dissolve the oil and allow the machine to operate satisfactorily.
3. Another method that may be used is to place a small quantity of powdered rosin between the clutch disc and the clutch plate. This is done by turning off the motor with the machine in neutral position, and by using a screw driver and the frame of the machine for leverage force the large main gear to move about two teeth in a counterclockwise direction. This will cause a small space to open between the clutch disc

and the clutch face. Now drop a small quantity of powdered rosin in this opening and start the machine.

4. If this does not correct the slipping, it is necessary that the clutch be removed and the disc wiped clean.

clean the clutch


1. With machine in neutral position, drive out the tapered pin in the clutch gear washer No. 83. This will allow the clutch to come apart.
2. Wipe both faces of the clutch clean and reassemble.

correct automatic tripping of cross tie

Note: Automatic tripping may occur on older tying machine models which don't have a wedge (part No. 112W) in the trip mechanism.

When cross tie machine trips automatically on the cross tie, the following remedy is recommended:

1. Turn off motor at switch.
2. Step on foot trip and hold down. This will cause the bell crank located at the left side of machine just under main table to remain open.
3. Using a small Pillar file, file a small amount off of surface "A" of bell crank.
4. Start machine and step on foot pedal and release instantly. If this does not cause the machine to stop for the cross tie, file off an additional amount of stock from surface "A" until the arm will revolve and stop when the foot pedal is engaged, and the foot instantly removed.



Or when machine trips automatically it may be due to one of the following reasons:

1. Trip rod may be bent and is binding. This can be easily straightened.
2. Vibration set up by dry bearing in clutch wheel. Bearing should be oiled.
3. Clutch block lever loosing its position on clutch fork roller. File surface "A".


The knot tells the story

This is a perfect knot



A perfect knot, like the illustration, has two long even loops extending out one side of the knot with one short end and one long end, the body of the knot is tight and hard. The stripper should be on the line where the upper and lower jaws meet at the lip of the lower jaw and very little space between them as the stripper pushes the twine off the knotter.

single loop



A knot with a single loop or "half knot" will not hold, as only one end is tied into the knot. The other end is free to pull out of the knot. This can be caused by the running tension being set too tight for the stringholder button tension, which will not leave enough free end of twine in the bottom to completely form the double loop knot. If this free end pulls out of the button at any time before the knife trap operates to cut the twine, and at the same time, pull out the residue of the free end, then the result will be a single loop knot. Another fault could be that too much running tension could cause the end in the button to jerk back part way, when the twine arm starts its revolution. This would not leave enough end to form a double loop knot. The remedy is to loosen the running tension to average easy running. Still another cause of single loops is a clogged stringholder. Keep the stringholder button clear of lint and bits of twine. Too much clogging will cause the twine to jerk out of the button as soon as the twine arm starts to revolve. Press on the release lever aid in removing lint and broken off ends. Do not use a sharp instrument to pry out lint between button and face of stringholder.

long and short loops



One long and one short loop, while not serious, is usually caused by wrong weight of twine for opening between jaws of knotter. Each knotter will take several different weights of twine, but if the twine used is too large, one loop can be caught in the back of the throat of the knotter and held there until released by the adjusting screw. To release turn knotter release screw in a clockwise direction.

break in twine in front of knot




If there are any broken plies in the twine running around the package and close to the knot, this usually caused by either friction against the mechanism or is due to too much tension in tying a firm, solid package. All edges except the stripper points must be kept smooth.

ragged ends



Frayed or ragged ends of twine at the knot indicate a dull knife. The knife can be sharpened by grinding on a fine emery wheel or honing on a whetstone. The ends should have very clean cuts. To remove the knife for sharpening, pull the knife trap forward with the hand, thus permitting easy access to the screw holding the knife or remove the A30 stringholder assembly.

Watch for improperly tied, poor knots; they indicate the machine requires proper adjustment to prevent development of trouble which might result in major repairs.



loose knot

When the body of the knot is loose and the loops slightly shorter than normal this indicates that the knotter release screw is set in too far, allowing the loops to release from the knotter too soon. Turn release screw in counterclockwise direction. The stripper could be too short.

short loops

Short loops and tight knot can be caused by lack of balance between the running tension and the stringholder button tension. With stringholder tension properly set, the running tension should be neither too tight nor too loose. If running tension is too loose, knotter does not take up enough slack causing strain on free end of twine held in button.

cut loop ends


One or more cut plies of twine in loop of knot are caused by the stripper points shearing against the side of knotter jaws when stripping. This shearing is not serious unless one or both loops are entirely cut. If only one or two plies are cut there is no weakening of the tie. To remedy, bend down top front end of the stripper with a light hammer.

very short loops and long ends

Very short loops and extra long ends caused either by knot slipping by the stripper or the knotter flat springs becoming weakened or both. The stripper to form a perfect knot should rub slightly against the side of knotter jaws and should be flush with top of knotter. It should also follow down the shoulder at the side of the jaws to get behind the knot for proper stripping. To close gap between stripper point and knotter, hit left side of stripper with hammer. The stripper is lightly case hardened. If knotter flat springs are weak, the loops will force out of knotter jaws before forming proper length. Replace weak springs with new ones to restore original performance.

For fast efficient maintenance, please study the illustrated examples of improperly tied knots, due to the wrong adjustments, and read the explanation on how to correct the trouble and obtain smooth machine operation.


STRINGHOLDER ASSEMBLY



STRIPPER



KNOTTER HEAD ASSEMBLY



Complete list of parts

Part No.	Description	Illustrated on Page Number	Part No.	Description	Illustrated on Page Number
<input type="checkbox"/> ○ 1	Frame—left end (tent).....	17	○ 9AS	Screw—set, short, cam wheel...	15
○ 2	Frame—front end (square)....	17	○ 9AL	Screw—set, long, cam wheel...	15
<input type="checkbox"/> ○ 3	Frame—near side, long.....	17	○ 9B	Key—cam wheel.....	15
3C	Frame—near side, clamp model		10 and 11	Cam—drawslide, regular (sold in pairs only).....	15
○ 3B	Frame—near side		○ 10PO and	Cam—drawslide, regular (sold in pairs only).....	15
○ 3FS	Screw—fillister head		○ 11PO	Pin—dowell—drawslide cam...	15
○ 3HS	Screw—hex. head		○ 10A	Screw—drawslide cam.....	15
<input type="checkbox"/> ○ 4	Frame—far side, long.....	17	○ 11A	Switch—knotter head cam....	15
4C	Frame—far side, clamp model		<input type="checkbox"/> ○ 12	Pin—switch.....	15
5L	Base—left side, long, regular...	17	<input type="checkbox"/> ○ 12A	Screw—switch.....	15
○ 5LPO	Base—left side, long.....	17	<input type="checkbox"/> ○ 12B	Rack—knotter.....	15
5DL	Base—left side, low.....	17	○ 13	Pin—knotter rack.....	15
5UL	Base—left side, high.....	17	○ 13A	Screw—knotter rack.....	15
5TL	Base—left side, tilted.....	17	○ 13B	Kick-out, clutch, regular.....	15
5R	Base—right side, long, regular...	17	○ 14	Kick-out, clutch, heavy	
○ 5RPO	Base—right side, long.....	17	○ 14A	Screw—clutch kick-out.....	15
5DR	Base—right side, low.....	17	<input type="checkbox"/> ○ 16	Cam riser.....	15
5UR	Base—right side, high.....	17	○ 16A	Screw—riser cam.....	15
5TR	Base—right side, tilted.....	17	△ <input type="checkbox"/> ○ A17L	Knotter head assembly—light (10 ply and below)	
5SS	Screw—socket set, base.....	17	△ <input type="checkbox"/> A17H	Knotter head assembly—heavy (12 ply and above)	
<input type="checkbox"/> ○ 6	Tie-Rod-Base (specify length measure shoulder to shoulder)...	17	○ A17A	Knotter head sub-assembly....	12
6E	Screw—hex. head, machine....	17	○ 17B	Pin	
○ 6A	Nut-base tie-rod.....	17	○ 17C	Oil cup.....	12—17
<input type="checkbox"/> 7	Trough—split type.....	17	○ 17D	Stud—knotter lever stop	
<input type="checkbox"/> ○ 7A	Bracket—trough, front.....	17	○ 17E	Stud—tip-up link	
7B	Bracket.....	17	△ ○ A18LM	Knotter body assembly— light, with miter gear.....	12
<input type="checkbox"/> 7L	Trough—laundry type		△ A18HM	Knotter body assembly— heavy, with miter gear	
<input type="checkbox"/> ○ 7PO	Trough—post office type		△ ○ 18JL	Jaw-knotter—light	
<input type="checkbox"/> 7RT	Trough—roll towel		△ ○ A18J	Knotter-jaw assembly.....	12
<input type="checkbox"/> 7MR	Trough—meat roll		△ 18JH	Jaw-knotter, heavy	
○ 7N	Nut—bracket screw.....	17	○ 18P	Pin-knotter jaw.....	12
○ 7S	Screw—bracket.....	17	○ 18R	Roller-knotter jaw.....	12
△ <input type="checkbox"/> ○ A8-17-30	Tying unit—complete, (composed of assemblies indicated in part number)		○ 19	Gear-miter, knotter.....	12
A8	Main table assembly—regular...	13—17	○ 19TP	Pin-taper, knotter miter gear...	12
A8B	Main table sub-assembly— regular.....	13	○ A20	Star wheel assembly, with miter gear.....	12
A8BC	Main table sub-assembly— clamp model		○ 21	Lever-knotter.....	12
○ A8BPO	Main table sub-assembly		○ 22	Screw—knotter lever.....	12
A8C	Main table assembly—clamp model.....	13	○ 22S	Screw-set, knotter lever screw...	12
○ A8PO	Main table assembly.....	13	○ 23	Spring-knotter flat	
○ 8C	Screw-set, knotter pivot.....	13	○ 23A	Screw-knotter flat spring.....	12
○ 8D	Stud—drawslide spring.....	13	○ 23B	Washer—knotter flat spring...	12
○ 8E	Stud—knotter head stop.....	13	○ 23C	Nut-knotter flat spring.....	12
○ 8F	Stud—drawslide lever.....	13	○ 24	Stud—knotter head roller.....	12
○ 8G	Stud—riser lever.....	13	○ 25	Roller—knotter head.....	12
○ 8H	Washer—riser lever.....	13	○ A26	Pivot assembly—knotter head...	12
○ 8I	Screw—riser lever.....	13	○ 26A	Screw—pivot assembly—lock...	17
○ 8R	Screw—hex. head, main table mounting.....	17	○ 26B	Washer—pivot assembly— lock screw.....	17
○ 8S	Screw—fil. head, main table mounting.....	17	○ 27	Screw—knife trap	
<input type="checkbox"/> ○ A9	Cam wheel assembly		○ 28	Screw—knotter release adjusting.....	13
<input type="checkbox"/> ○ 9	Cam wheel.....	15			

○ Used in post office models, too. Order may be written with "P.O." appended to part number.

☐ Must order with machine serial number. △ Specify twine size used. ☆ Used with backgeared models.

Part No.	Description	Illustrated on Page Number	Part No.	Description	Illustrated on Page Number
○ 28A	Nut—knotter release screw	13	○ 49D	Stud-roller—drawslide lever	13
○ 29	Post—knotter release	13	○ 50	Spring—drawslide (post office trip)	13—15
○ 29A	Pin—knotter release post	13	○ 50A	Pin—grooved	13
△ □ ○ A30L	Stringholder assembly— light, regular		○ A51	Tip-up assembly	13
△ □ ○ A30H	Stringholder assembly— heavy, regular		○ 51A	Rivet—tip-up lever	13
△ □ ○ A30CL	Stringholder assembly— light, clamp models		○ 51L	Lever—tip-up	13
△ □ ○ A30CH	Stringholder assembly— heavy, clamp models		△ □ ○ 52	Stripper—(styles listed below)	13
△ □ ○ 30L	Stringholder sub-assembly— light, regular	14	△ □ ○ 52A	Stripper—light, regular	
△ □ 30H	Stringholder sub-assembly— heavy, regular		△ □ 52B	Stripper—heavy, regular	
△ □ 30CL	Stringholder sub-assembly— light, clamp model		△ □ 52LA	Stripper—light, laundry	
△ □ 30CH	Stringholder sub-assembly— heavy, clamp model		△ □ 52LB	Stripper—heavy, laundry	
○ 30FS	Screw-stringholder mounting		○ 53	Screw-stripper	13
○ 30P	Pin—spring perch	14	○ 54	Spring-stripper	13
○ 30PP	Pin—stringholder locating	14	○ 55	Lever-riser	13
○ A31L	Knife trap assembly— long lever	14	○ 55A	Screw-riser lever stop	13
A31S	Knife trap assembly—short lever (for very heavy ply only)		○ 55B	Nut-riser lever stop screw	13
○ 31	Knife trap	14	○ 56	Guide—riser pin	13
○ 32L	Lever—long, knife trap	14	○ 56A	Screw—guide mounting	13
32S	Lever—short, knife trap (for very heavy ply only)		○ 57	Pin—riser	13
○ 33	Screw—knife trap pivot	14	58	Spring—trip	15
○ 33L	Washer-lock—pivot screw	14	○ 59	Bell-crank trip	15
○ 33N	Nut—pivot screw	14	○ 59PO	Bell-crank trip—regular	
○ 34	Rivet—knife trap	14	60A	Nut-pivot screw (clamp model & replacement)	
○ 35	Spring—knife trap	14	60	Screw-pivot, (clamp model & replacement on old style)	
○ 35A	Stud-knife trap spring	14	○ 61	Screw-pivot	15
○ 36	Knife	14	○ 61A	Nut-pivot screw	15
○ 37	Screw—knife mounting	14	○ 61B	Washer-lock—pivot screw	15
○ 38	Button—stringholder	14	62	Rod-trip—(sizes below)	17
○ 39L	Spring—light, stringholder button (for 10 ply and below)	14	○ 62PO	Rod-trip	15
39H	Spring, heavy, stringholder button (for 12 ply and above)		□ 62S	Rod-trip, short (23")	
○ 40	Nut—stringholder button	14	□ 62T	Rod-trip, medium (24½")	
○ 41	Washer—stringholder button	14	□ 62U	Rod-trip, long (28½")	
○ 42	Lever-release, stringholder button	14	62N	Nut-trip rod	17
○ 43	Screw-release lever	14	62W	Washer-trip rod	17
○ A45	Drawslide assembly—regular (sold with A47 only)	13	○ A63	Fork assembly—clutch	
A45C	Drawslide assembly—clamp type (sold with A47 only)	13	○ 63	Fork—clutch	15
A45D	Drawslide assembly— double headed type		○ 64	Roller-clutch fork	15
○ A47	Cap assembly—drawslide	13	○ 65	Screw—clutch fork roller	15—17
○ 47A	Roller—drawslide cap	13	○ 66H	Pin-clutch fork pivot	15
○ 47B	Stud-roller—drawslide cap	13		(includes cotter pins)	
○ 47C	Screw—drawslide cap	13	○ 67	Bearing—lower	15
○ 47D	Washer-lock—drawslide cap	13	○ 67S	Screw—lower bearing	15
○ A49	Lever assembly—drawslide		□ A68	Loose table assembly	17
○ 49A	Washer—lever retaining	13	○ 68P1	Pin—loose table retaining, for ¾" diam. stud	16—17
○ 49B	Screw—lever retaining	13	68P2	Pin—loose table retaining, for ⅞" diam. stud	16
○ 49C	Roller—drawslide lever	13	68S	Housing—ball bearing, double (loose table)	
			68S short	Housing—ball bearing, single (loose table)	
			69	Yoke—clamp	
			69R	Rod—yoke	
			69T	Screw—thumb, yoke clamp	
			70	Lever—short	
			70P	Pin—taper, short lever	
			70R	Roller—short lever	
			70S	Stud-roller—short lever	
			71	Lever—long	
			71LS	Stud—large, long lever	

○ Used in post office models, too. Order may be written with "P.O." appended to part number.

□ Must order with machine serial number. △ Specify twine size used. ☆ Used with backgeared models.

Part No.	Description	Illustrated on Page Number	Part No.	Description	Illustrated on Page Number
71SS	Stud—small, long lever		□ 79AD	Pulley assembly—double clutch, small (8¼" diam.)	15
72	Rod—yoke lever pivot		□ 79AL	Pulley assembly—single clutch, large (9¼" diam.)	
72C	Collar—pivot rod		□ 79ADL	Pulley assembly—double clutch, large (9¼" diam.)	
72CS	Screw—pivot rod collar		○ 79B	Rivet—clutch disc	15
73	Joint—yoke		○ 79C	Bearing—clutch	15
73P	Pin—taper, yoke joint		○ 79E	Disc—clutch	15
74	Fork—yoke		○ 80A	Pinion—clutch shaft, 1-cut	15
74A	Plate—yoke fork cap		80B	Pinion—clutch shaft, 2-cut	15
74B	Rivet—cap plate		○ 80P	Pin—taper, pinion	15
74C	Pin—yoke fork		□ 81	Shaft—single clutch	15
74D	Plate—narrow, fork guide		□ 81A	Shaft—double clutch	15
74E	Plate—wide, fork guide		○ 82	Clutch member—outer	15
74F	Screw—guide plate		82A	Clutch member—inner	15
□ ○ 75A	'V' Belt	17	82B	Pin-taper—double clutch member	15
75B	Bushing—motor pinion		○ 83	Collar—clutch pulley	15
□ 75P-11	Pinions—motor		○ 83A	Collar—clutch shaft end	15
□ 75P-12	Pinions—motor		○ 83D	Pin-collar—clutch pulley	15
□ 75P-13	Pinions—motor		○ 83E	Pin-end collar—clutch pulley	15
□ 75P-14	Pinions—motor		□ 84	Spring—clutch	15
□ 75P-15	Pinions—motor		□ 85	Twine arm	16
□ 75P-18	Pinions—motor		□ A85BB	Twine arm assembly—ball bearing	16
□ 75P-20	Pinions—motor		□ A85NB	Twine arm assembly—needle bearing	16
□ 75P-22	Pinions—motor		□ ○ A85BrB	Twine arm assembly—bronze bearing	16—17
□ 75-S	Pinions—motor	17	□ ☆ A85BG	Twine arm assembly—back geared	16
□ ○ 75S-15	Sheave—motor		○ 85PO	Twine arm	
□ 75S-17	Sheave—motor		□ 85-102	Twine arm—10" 2 wrap	
□ 75S-20	Sheave—motor		□ 85-162	Twine arm—16" 2 wrap	
□ 75S-22	Sheave—motor		□ 85-163	Twine arm—16" 3 wrap	
○ 75SS	Screw—set, motor sheave	17	□ 85-182-4	Twine arm—18" 2 wrap ext. 4"	
75Q	Key—fibre pinion		□ 85-183-4	Twine arm—18" 3 wrap ext. 4"	
□ 76	Gear—main cam	15	□ 85-202-4	Twine arm—20" 2 wrap ext. 4"	
□ 76B	Gear—main cam (for two wrap cross tie & laundry models)		□ 85-203-4	Twine arm—20" 3 wrap ext. 4"	
□ 76E	Gear—main cam (single wrap clamp models)		□ 85-232-4	Twine arm—23" 2 wrap ext. 4"	
□ ○ 76EP	Gear—main cam (single wrap models)		□ 85-233-4	Twine arm—23" 3 wrap ext. 4"	
□ 76F	Gear—main cam (for 10" & 16" cross tie models & all one-way machines)		□ 85-262	Twine arm—26" 2 wrap	
○ 76SS	Screw-set—short, main cam gear	15	□ 85-263	Twine arm—26" 3 wrap	
○ 76SL	Screw-set—long, main cam gear	15	85BR2	Bearing—bronze, 2 wrap twine arm	
○ 77	Key—main cam gear	15	○ 85BR3	Bearing—bronze, 3 wrap twine arm	
□ ○ 78	Shaft—main	15	85C	Collar—twine arm stem	
□ ○ A79	Clutch gear & shaft assembly—single		85CS	Screw-set, collar	
□ A79D	Clutch gear & shaft assembly—double		○ 852D1	Ring—retaining	16
□ ○ A79A	Clutch pulley & shaft assembly—single, (8¼" diam.)		○ 85E	Eye—twine guide	16
□ A79AD	Clutch pulley & shaft assembly—double (8¼" diam.)		85F	Plate-bearing retaining	
	Clutch pulley & shaft assembly—large, single (9¼" diam.)		85FP	Pin-plate	
	Clutch pulley & shaft assembly—large, double (9¼" diam.)		85FS	Screw-plate	
□ 79	Gear assembly—single clutch		85GP	Pin—drawback spring	
□ 79D	Gear assembly—double clutch		☆ 85K	Gear—21T. twine arm transfer	
□ ○ 79A	Pulley assembly—single clutch, small (8¼" diam.)	15	☆ 85LS	Gear—42T. twine arm pivot	
			☆ 85LL	Gear-back—loose table	
			85M	Key-sprocket—twine arm	
			☆ 85N	Shaft-transfer—twine arm	
			☆ 85NA	Bearing-transfer shaft—twine arm	

○ Used in post office models, too. Order may be written with "P.O." appended to part number.

□ Must order with machine serial number. △ Specify twine size used. ☆ Used with backgeared models.

Part No.	Description	Illustrated on Page Number	Part No.	Description	Illustrated on Page Number
85P2	Pin—15T. sprocket, twine arm		○ 110P	Disc—fibre	
85P3	Pin—12T. sprocket, twine arm		110PR	Disc—foam plastic	
85Q	Pin-taper—twine arm transfer gear		○ 110T	Screw—can mounting	
85R	Race-needle bearing—1" long		□ 111	Pad—straight yoke	
85S	Spacer—twine arm stem— $\frac{3}{4}$ " long		□ 111N	Nut—straight yoke pad	
85TB-A	Bearing-needle— $\frac{1}{2}$ " long		□ 111S	Screw—straight yoke pad	
85TB-B	Bearing-needle—1" long		112	Lever—clutch block kickout, large (replacement-old style)	
85TB-S	Spacer-bearing—1 $\frac{1}{8}$ " long		○ 112A	Lever—clutch block kickout, small	15
☆ 85U	Bearing-ball—T. A. pivot		○ 112W	Wedge—kickout lever	15
☆ 85V	Housing—ball bearing		○ 112WS	Stud—kickout lever wedge . . .	15
85W	Washer-thrust, T.A. stem		115A	Screw—tension booster adjusting	
☆ 85X	Flag-T.A. back gear		115TB-B	Bracket—tension booster	
☆ 85XS	Screw—flag mounting		115TB-R	Rocker arm—tension booster	
90A	Caster—2 $\frac{1}{2}$ " plastic, regular . .	17	115G	Guard—tension booster	
90H	Caster—3" plastic, lock		115H	Screw—tension booster guard	
○ 90J	Caster—3" plastic, regular		115S	Screw—tension booster bracket mounting	
○ 90S	Sleeve—caster	17	115T	Screw—tension booster rocker pivot	
○ 91A	Nut—knurled tension—small . .	17	115U	Nut—tension booster rocker pivot screw	
91B	Nut—knurled tension—large (used on tension booster only)		115V	Spring—compression, tension booster	
○ 92	Spring—tension	17	115W	Plunger—compression spring, tension booster	
○ 92Q	Stud—tension spring		○ A116	Running tension assembly	
○ 92R	Screw—tension spring		○ 117	Screw—assembly mounting . . .	17
○ 93G	Guard—running tension		118C	Collar-T.B. plunger	
93M	Bracket—large tension holder .	17	118P	Plunger-tension—booster	
93S	Screw—bracket mounting		118S	Screw-set—T.B. plunger collar	
○ A94	Lever assembly—pressure trip .	15	119	Guide—T.B.	
□ 94L	Lever-trip—model 'L'		119A	Stud—T.B. spring	
□ 94M	Lever-trip—model 'M'	17	119B	Spring—tension booster	
□ 94U	Bracket—'U' trip support		119C	Stud—T.B. spring rocker	
□ 94UI	Treadle—'U' trip		119N	Nut-T.B. guide lock	
94N	Washer-trip lever pivot	17	120	Cam—tension booster	
94P	Screw-trip lever pivot	17	121	Screw—T.B. cam	
○ 94PS	Spring—pressure trip	15	122	Pin—T.B. cam	
○ 94Q	Stud—pressure trip spring		□ ○ 123C	Chain-roller	17
○ 94S	Screw—pressure trip bearing . .	13—15	□ ○ A123SA	Chain gear assembly	15
○ 94T	Bearing—pressure trip	13—15	○ 123SA	Shoe—small radius, chain gear .	15
○ 94TP	Pin—bearing locating		123SB	Shoe—large radius, chain gear (roll towel & 10" models only)	
○ 94V	Collar-P.T. pivot stud	15	○ 123R	Rivet—chain gear shoe	
○ 94W	Screw-set—collar		123D2	Stud—chain gear, 2W	15
96	Spring—straight hook pressure		○ 123D3	Stud—chain gear, 3W	
A103-6	Drawback lever assembly—6"		☆ 123D2BG	Stud—chain gear, 2W back gear	
○ A103-8 $\frac{1}{2}$	Drawback lever assembly— 8 $\frac{1}{2}$ "	16	☆ 123D3BG	Stud—chain gear, 3W back gear	
A103-10	Drawback lever assembly—10"		123MR-BG	Stud—chain gear, meat roll	
A103-12	Drawback lever assembly—12"		○ 123E	Screw-set, chain gear stud . . .	17
103R	Rivet—drawback pivot arm		□ 124-10	Shield—10" machine	
103S	Screw-set—drawback	16	○ 124-16	Shield—16" machine	17
○ 104L	Spring—light drawback (up to 16")	16	□ 124-18	Shield—18" machine	
104M	Spring—medium drawback (18" model & above)		□ 124-20	Shield—20" machine	
105	Clip—drawback spring	16	□ 124-23	Shield—23" machine	
106N	Screw—drawback	16	□ 124-26	Shield—26" machine	
○ 110	Twine can—regular	17	○ 124S	Screw—shield mounting	17
110JO	Twine can—jumbo, outside mounting		□ 125	Brake—casting	17
110JU	Twine can—jumbo, under machine mounting		□ A125	Brake assembly	
○ 110CL	Cone—wooden, large		□ ○ A125PO	Brake pad assembly	17
110CS	Cone—wooden, small				
○ 110D	Screw—cone mounting				

○ Used in post office models, too. Order may be written with "P.O." appended to part number.
□ Must order with machine serial number. △ Specify twine size used. ☆ Used with backgeared models.

Part No.


Description

Illustrated on
Page Number

<input type="checkbox"/> 125A	Rod—brake adjusting.....17
<input type="checkbox"/> 125APO	Rod—brake adjusting
<input type="checkbox"/> 125BL	Nut—brake adjusting rod.....17
<input type="checkbox"/> 125WL	Washer—brake adjusting rod.....17
<input type="checkbox"/> 125P	Pivot—brake.....17
<input type="checkbox"/> 125Q	Pin—brake pivot cotter.....17
<input type="checkbox"/> 126	Plate—motor.....17
<input type="checkbox"/> 126A	Bracket—motor plate.....17
<input type="checkbox"/> 126N	Nut—bracket screw
<input type="checkbox"/> 126R	Riser—motor plate.....17
<input type="checkbox"/> 126S	Screw—frame.....17
<input type="checkbox"/> 127	Standard—knotter
<input type="checkbox"/> 127S	Screw—knotter standard.....17
<input type="checkbox"/> 128	Loop—jumbo twine can
<input type="checkbox"/> 128A	Loop—regular twine can.....17
<input type="checkbox"/> 128AS	Screw—loop mounting.....17
<input type="checkbox"/> 129A	Cord set—regular, 8 ft. with switch.....17
<input type="checkbox"/> 129B	Cord set—grounded, 8 ft. with switch
<input type="checkbox"/> 129C	Cord set—3 phase, 8 ft. with switch
<input type="checkbox"/> 129DB	Cord set—post office, 12 ft. with switch & pilot light
<input type="checkbox"/> 129DBL	Light—pilot
<input type="checkbox"/> 129F	Switch toggle
<input type="checkbox"/> 129S	Screw—switch mounting.....17
<input type="checkbox"/> 130	Motor—electric (give information from motor specification plate).....17
<input type="checkbox"/> 132E10	Guard—expanded metal, 10" machine
<input type="checkbox"/> 132E16	Guard—expanded metal, 16" machine.....17
<input type="checkbox"/> 132E16PO	Guard—expanded metal
<input type="checkbox"/> 132E18	Guard—expanded metal, 18" machine
<input type="checkbox"/> 132E20	Guard—expanded metal, 20" machine
<input type="checkbox"/> 132E23	Guard—expanded metal, 23" machine
<input type="checkbox"/> 132S18	Guard—strap metal, 18" machine
<input type="checkbox"/> 132S20	Guard—strap metal, 20" machine
<input type="checkbox"/> 132S23	Guard—strap metal, 23" machine
<input type="checkbox"/> 132S34	Guard—strap metal, 34" machine
<input type="checkbox"/> 132S10MR	Guard—strap metal, 10" meat roll machine
<input type="checkbox"/> 132S16MR	Guard—strap metal, 16" meat roll machine
<input type="checkbox"/> 132E8	Guard—expanded metal, 8" roll towel machine

A17L—Knotter Head Assembly

Light (10 ply and below)




<input type="checkbox"/> A17A	Knotter head sub-assembly
<input type="checkbox"/> 17C	Oil cup
<input type="checkbox"/> 18J	Knotter-jaw assembly
<input type="checkbox"/> 18LM	Knotter body assembly—light, with miter gear
<input type="checkbox"/> 18P	Pin-knotter jaw
<input type="checkbox"/> 18R	Roller-knotter jaw
<input type="checkbox"/> 19	Gear-miter knotter
<input type="checkbox"/> 19TP	Pin-taper, knotter miter gear
<input type="checkbox"/> A20	Star wheel assembly, with miter gear
<input type="checkbox"/> 21	Lever-knotter
<input type="checkbox"/> 22	Screw—knotter lever
<input type="checkbox"/> 22S	Screw-set, knotter lever screw
<input type="checkbox"/> 23	Spring—knotter flat
<input type="checkbox"/> 23A	Screw-knotter flat spring
<input type="checkbox"/> 23B	Washer—knotter flat spring
<input type="checkbox"/> 23C	Nut—knotter flat spring
<input type="checkbox"/> 24	Stud—knotter head roller
<input type="checkbox"/> 25	Roller—knotter head
<input type="checkbox"/> A26	Pivot assembly—knotter head

☐ Used in post office models, too. Order may be written with "P.O." appended to part number.

☐ Must order with machine serial number. ☐ Specify twine size used. ☐ Used with backgeared models.

A8 Main Table Assembly



Regular



- A8B Main table sub-assembly, regular
- A8C Main table assembly—clamp model
- A8PO Main table assembly
- 8C Screw set, knotter pivot
- 8D Stud—drawslide spring
- 8E Stud—knotter head stop
- 8F Stud—drawslide lever
- 8G Stud—riser lever
- 8H Washer—riser lever
- 8I Screw—riser lever
- 28 Screw—knotter release adjusting
- 28A Nut—knotter release screw
- 29 Post—knotter release
- 29A Pin—knotter release post
- A45 Drawslide assembly—regular (sold with A47 only)

- A45C Drawslide assembly—clamp type (sold with A47 only)


- A47 Cap assembly—drawslide
- 47A Roller—drawslide cap
- 47B Stud-roller, drawslide cap
- 47C Screw—drawslide cap
- 47D Washer-lock—drawslide cap
- A49 Lever assembly—drawslide
- 49A Washer—lever retaining
- 49B Screw—lever retaining
- 49C Roller—drawslide lever
- 49D Stud-roller, drawslide lever
- 50 Spring—drawslide (post office trip)
- 50A Pin-grooved
- A51 Tip-up assembly
- 51A Rivet—tip-up lever
- 51L Lever—tip-up
- △ □ 52 Stripper
- 53 Screw-stripper
- 54 Spring-stripper
- 55 Lever-riser
- 55A Screw-riser lever stop
- 55B Nut-riser lever stop screw
- 56 Guide—riser pin
- 56A Screw—guide mounting
- 57 Pin—riser
- 94S Screw—pressure trip bearing
- 94T Bearing—pressure trip



A30L—Stringholder Assembly

Light, Regular (Post Office)


10 Ply Twine and Under




- 27 Screw—knife trap
- 30FS Screw—stringholder mounting
- △ □ ○ 30L Stringholder sub-assembly—light, regular
- 30P Pin—spring perch
- 30PP Pin—stringholder locating
- A31L Knife trap assembly, long lever
- 31 Knife trap
- 32L Lever—long, knife trap
- 33 Screw—knife trap pivot
- 33L Washer—lock, pivot screw
- 33N Nut—pivot screw
- 34 Rivet—knife trap
- 35 Spring—knife trap
- 35A Stud—knife trap spring
- 36 Knife
- 37 Screw—knife mounting
- 38 Button—stringholder
- 39L Spring—light, stringholder button (for 10 ply and below)
- 40 Nut—stringholder button
- 41 Washer—stringholder button
- 42 Lever—release, stringholder button
- 43 Screw—release lever

Cam Wheel, Clutch & Chain Gear Assemblies

- ○ 9 Cam wheel
- 9AL Screw—set, long, cam wheel
- 9AS Screw—set, short, cam wheel
- 9B Key—cam wheel
- 10 & 11 Cam—drawslide, regular—(sold in pairs only)
- 10A Pin—dowel, drawslide cam
- 11A Screw—drawslide cam
- ○ 12 Switch—knotter head cam
- ○ 12A Pin—switch
- ○ 12B Screw—switch
- 13 Rack—knotter
- 13A Pin—knotter rack
- 13B Screw—knotter rack
- 14 Kick-out, clutch, regular
- 14A Screw—clutch kick-out
- ○ 16 Cam riser
- 16A Screw—riser cam
- 50 Spring—drawslide (post office trip)
- 58 Spring—trip
- 59 Bell crank—trip
- 61 Screw—pivot
- 61A Nut—pivot screw
- 61B Washer—lock, pivot screw
- 62PO Rod—trip
- 63 Fork—clutch
- 64 Roller—clutch fork
- 65 Screw—clutch fork roller
- 66H Pin—clutch fork pivot (includes cotter pins)
- 67 Bearing—lower
- 67S Screw—lower bearing
- 76 Gear—main
- 76SL Screw—set, long, main cam gear
- 76SS Screw—set, short, main cam gear
- 77 Key—main cam gear
- ○ 78 Shaft—main
- ○ 79A Pulley assembly—single clutch, small (8¼ diam.)
- 79AD Pulley assembly—double clutch, small (8¼ diam.)
- 79B Rivet—clutch disc
- 79C Bearing—clutch
- 79E Disc—clutch
- 80A Pinion—clutch shaft, 1-cut
- 80B Pinion—clutch shaft, 2-cut
- 80P Pin—taper, pinion
- ○ 81 Shaft—single clutch
- 81A Shaft—double clutch
- 82 Clutch member—outer



DOUBLE CLUTCH ASSEMBLY




POST OFFICE PRESSURE TRIP

- 82A Clutch member—inner
- 82B Pin-taper, double clutch member
- 83 Collar—clutch pulley
- 83A Collar—clutch shaft end
- 83D Pin-collar—clutch pulley
- 83E Pin-end collar—clutch pulley
- ○ 84 Spring—clutch
- A94 Lever assembly—pressure trip
- 94PS Spring—pressure trip
- 94S Screw—pressure trip bearing
- 94T Bearing—pressure trip
- 94V Collar—P.T. pivot stud
- 112A Lever—clutch block kickout, small
- 112W Wedge—kickout lever
- 112WS Stud—kickout lever wedge
- 123D2 Stud—chain gear, 2W
- ○ A123SA Chain gear assembly

○ Used in post office models, too. Order may be written with "P.O." appended to part number.
 □ Must order with machine serial number. △ Specify twine size used. ☆ Used with backgeared models.


Twine Arm Assemblies



- 68P1 Pin—loose table retaining, for 3/4" dia. stud
- 68P2 Pin—loose table retaining, for 7/8" dia. stud
- A85BB Twine arm assembly—ball bearing
- ☆ A85BG Twine arm assembly—back geared
- ○ A85BrB Twine arm assembly—bronze bearing
- A85NB Twine arm assembly—needle bearing
- 85 Twine arm
- 852D1 Ring—retaining
- 85E Eye—twine guide
- 103S Screw—set—drawback
- A103-8 1/2 Drawback lever assembly—8 1/2"
- 104L Spring—light drawback (up to 16")
- 105 Clip—drawback spring
- 106N Screw—drawback

Base Parts

- ○ 1 Frame—left end (tent)
- 2 Frame—front end (square)
- ○ 3 Frame—near side, long
- ○ 4 Frame—far side, long
- 5L Base—left side, long, regular
- 5R Base—right side, long, regular
- 5LPO Base—left side, long
- 5RPO Base—right side, long
- 5DL Base—left side, low
- 5DR Base—right side, low
- 5UL Base—left side, high
- 5UR Base—right side, high
- 5TL Base—left side, tilted
- 5TR Base—right side, tilted
- 5SS Screw—socket set, base
- 6A Nut—base tie-rod
- ○ 6 Tie-rod—base (specify length measure shoulder to shoulder)
- 6E Screw—hex. hd. cap
- 7 Trough—split type
- ○ 7A Bracket—trough, front
- 7B Bracket
- 7N Nut—bracket screw
- 7S Screw—bracket
- A8 Main table assembly, regular
- 8R Screw—hex. hd., main table mtg.
- 8S Screw—fil. hd., main table mtg.
- 17C Oil cup
- 26A Screw—pivot assembly lock
- 26B Washer—pivot assembly lock screw
- 62 Rod—trip
- 62N Nut—trip rod
- 62W Washer—trip rod
- A68 Loose table assembly
- 68P1 Pin—loose table retaining, for 3/4" diam. stud
- ○ 75A 'V' Belt
- 75S Pinions—motor
- 75SS Screw—set, motor sheave
- ○ A85BrB Twine arm assembly—bronze bearing
- 90A Caster—2 1/2" plastic, regular
- 90S Sleeve—caster
- 91A Nut—Knurled tension—small
- 92 Spring—tension
- 93M Bracket—large tension holder
- 94M Lever—trip, model 'M'
- 94N Washer—trip lever pivot
- 94P Screw—trip lever pivot
- 110 Twine can—regular
- 117 Screw—assembly mounting
- ○ 123C Chain—roller
- 123E Screw—set, chain gear stud
- ○ 124-16 Shield—16" machine




- 124S Screw—shield mounting
- 125 Brake casting
- 125A Rod—brake adjusting
- A125PO Brake pad assembly
- 125BL Nut—brake adjusting rod
- 125WL Washer—brake adjusting rod
- 125P Pivot—brake
- 125Q Pin—brake pivot cotter
- 126 Plate—motor
- 126A Bracket—motor plate, reg.
- 126R Riser—motor plate
- 126S Screw—frame
- 127S Screw—knotter standard

- 128A Loop—regular twine can
- 128AS Screw—loop mounting
- 129A Cord set—regular, 8 ft. with switch
- 129S Screw—switch mounting
- 130 Motor—electric
(give information from motor spec. plate)
- 132E16 Guard—expanded metal, 16" machine

○ Used in post office models, too. Order may be written with "P.O." appended to part number.
 □ Must order with machine serial number. △ Specify twine size used. ☆ Used with backgeared models.

OTHER BASE STYLES

The RIGHT model



There's a Bunn machine that's just right for your operation . . . whether you tie large cartons or a handful of pencils. Soft packages, mail, irregular shapes, boxes, meats, newspapers, anything that can be tied by hand can be tied better and much faster by a Bunn Package Tying Machine. A Bunn Representative will help you select the model you need . . . to save time and money.

B. H. BUNN COMPANY


~~7605 Vincennes Ave. • Chicago, Illinois 60620~~

~~Area Code 312 / 483-3222~~

NEW ADDRESS: 12550 S. Lombard Lane, Alsip, Ill. 60658


NEW TELEPHONE: (312) 388-7600

The RIGHT twine



The right twine can improve production 50% because it runs through the machine smoothly . . . it is free of knots and irregularities that snag and break. And the high, uniform strength of Bunn Twine assures dependable ties under all types of tying conditions.

There are big differences in tying machine twines . . . and the small additional cost of Bunn Tying Machine Twine pays big dividends. Ask a Bunn Representative for the proof.



BUNN SUPPLY COMPANY

~~7605 Vincennes Ave. • Chicago, Illinois 60620~~

~~Area Code 312 / 483-3222~~

NEW ADDRESS: 12550 S. Lombard Lane, Alsip, Ill. 60658

NEW TELEPHONE: (312) 388-7600

BUNN®

PACKAGE TYING MACHINES & TYING MACHINE TWINES